REAR HITCH KIT (15696)

This kit is ONLY used on 2014 and newer 200 series LUTVs





As illustrated below, this kit consists of:

16043-2 Hitch Mount Qty: 1 15422 3/8 Bolt Qty: 4 15442 3/8 Nut Qty: 4





Procedure:

- Position the hitch mount so that the bolt holes line up with the swingarm bolt holes and so that the hitch mount is nearly parallel to the ground.
- Install the 3/8" bolt from the outside such that they pass through the swingarm and hitch mount.
- Install the lock nuts and tighten.

