

## Skid Plate Installation

### Contents:

- 1 – Skid Plate
- 4 – U-bolts
- 8 – 5/16" Nylock nuts
- 8 – 5/16" flat washers

### Tools required:

- ½" wrench or socket



1. Place the skid plate on the ground under the transmission. The end with the square notch goes toward the rear. The solid end goes toward the front.

2. Loosely fasten the front of the skid plate with U-bolts to the back side of the cross tube ahead of the transmission as shown. Place a washer under each nut.



3. Rotate the rear of the skid plate up so that it is fastened on each side of the receiver hitch with U-bolts.
4. Tighten all the U-bolts so that each leg of the bolt has approximately the same length of bolt through each nut.

