

# Table of Contents

<b>Section 1</b>	<b>Introduction / Features</b> .....	<b>pages 2-3</b>
	Your vehicle's model, VIN and serial number .....	see below
<b>Section 2</b>	<b>Safety</b> .....	<b>pages 4-14</b>
	Safety labels and locations .....	5-7
	Warnings: operation .....	8-9
	Warnings: maintenance .....	10
	Warnings: fuel, tires, vehicle care, batteries .....	11
	Warnings: 48 volt .....	12
	Responsible operation and rider safety .....	13-14
<b>Section 3</b>	<b>Operation</b> .....	<b>pages 15-20</b>
	Before you drive .....	15-16
	General operation: gas models .....	17-18
	General operation: electric models .....	18
	Driving recommendations .....	19-20
<b>Section 4</b>	<b>Maintenance</b> .....	<b>pages 21-34</b>
	Replacement parts / maintenance schedule .....	21
	Maintenance: engine .....	22-23
	Maintenance: drivetrain .....	24-28
	Maintenance: chassis, steering & suspension .....	29-30
	Maintenance: brakes & tires .....	30-31
	Maintenance: vehicle care .....	31
	Maintenance: transportation & storage .....	32
	Maintenance: battery & electrical .....	33-34
<b>Section 5</b>	<b>Troubleshooting</b> .....	<b>pages 35-36</b>
<b>Section 6</b>	<b>Wiring diagrams</b> .....	<b>pages 37-42</b>
	Kohler 277cc / Honda 390cc .....	37
	Kohler 429cc .....	38
	Vanguard 479cc .....	39
	Kohler 674cc .....	40
	48 volt .....	41-42
<b>Section 7</b>	<b>Specifications</b> .....	<b>pages 43-44</b>
<b>Section 9</b>	<b>Warranty</b> .....	<b>pages 45-47</b>
	Full Size UTV Warranty Statement .....	45
	Service and Warranty Contact Information .....	46
	UTV Setup and Pre-Delivery Checklist .....	47
<b>Pre Drive Inspection Checklist</b> .....		<b>Back Cover</b>

## YOUR PRODUCT IDENTIFICATION NUMBER (PIN)

Making sure your PIN is noted correctly greatly reduces any delays in getting help with parts, accessories or any warranty work.

MODEL:

17 CHARACTER PIN:

A	4	P															
letter / digit / letter	letter/digit	letter/digit	letter/digit	letter/digit	letter	letter/digit	letter	letter	letter	letter	letter	letter	letter	letter	letter	letter	letter

THE PIN PLATE IS LOCATED BELOW THE UTV STEERING WHEEL

